



Lenovo ThinkPad Yoga 14 20FY Battery Replacement

This guide explains how to easily and safely locate and remove the battery from your Lenovo Thinkpad Yoga.


Written By: Jacob Singer



INTRODUCTION

This guide explains how to safely remove the battery from your Lenovo Thinkpad Yoga 14 20FY.

Step 1 — Back Cover



- Remove the indicated 9 M2 x 6 mm nylon-coated screws using a Phillips head screwdriver.

i The screws do not come all the way out. Do not force them out.


Step 2




- After removing all of the screws, gently lift up on all covers to remove the back plate and reveal the interior of the device.



Step 4



Step 5



- There will also be a clip that attaches the battery to the rest of the laptop. Unclasp the clip from its holding to completely free the battery.

Step 6



- Once all wires are detached from the rest of the computer, remove the battery from the laptop and replace.

To reassemble your device, follow these instructions in reverse order.

